



# Index

<b>1. Introduction.....</b>	<b>3</b>
<b>2. Physical installation.....</b>	<b>4</b>
2.1. The sensors.....	4
2.2. Power inputs and outputs.....	5
<b>3. The Starling's web server.....</b>	<b>8</b>
3.1. The homepage.....	9
3.2. The control panel.....	9
3.3. The relays and sensors page.....	10
3.4. The software and firmware updates page.....	11
3.5. The configuration page.....	12
3.6. The public panel.....	13
<b>4. Starling API.....</b>	<b>15</b>
4.1. SLP commands.....	15
<b>5. Disclaimers.....</b>	<b>18</b>

## 1. Introduction


The Starling is our shared observatory controller. It is designed to enable several users to seamlessly interact with a shared observatory, while including safeguards for the owner of the roof (the *sentinel*) to be able to take over where necessary.

In a nutshell, the Starling handles open and close requests from users, allows them to interact with the roof as if they were the only ones sending commands to it, and ensures that ASCOM compliance is maintained in the same way. From the user's point of view, interacting with a shared roof via the Starling is analogous to interacting with an individual roof using the [Dragonfly](#) or the [Caterpillar](#).

The *sentinel* is also able to control some observatory devices, such as dehumidifiers, lights, and alarms.

## 2. Physical installation

Setting up your Starling should be an easy process. If you own a Dragonfly, you can probably [skip to the next section](#). Otherwise keep reading.




The Starling's sticker aims at making the setup process as smooth as possible. At a glance, we can see all the sensors, as well as most of the relays (outputs) and power inputs, have labels. Since it's designed with shared observatories in mind, these features will be common to most of them, and the device has been designed accordingly (although it is possible to accommodate it to different setups).

### 2.1. The sensors

The first two sensors are straightforward—they should be the open and closed sensors of our roof.

The four sensors inside the red box are associated with the safety of the observatory. The



**unsafe** sensor can be connected to a safety monitor (say, for example, the [CloudWatcher](#)), **power fail** can be connected to a relay that remains open while it's receiving power, and the **emergency** sensor can be connected to a manual switch to activate an alarm or some other device. By default, any of these being active will trigger the closing of the roof. The **security override** sensor enables you to override this behaviour. Depending on your setup, you may wish to hook this up to a physical button or switch, or something you can access remotely (there is, however, a remote security override setting that can be toggled from the [web server](#) or sent as a command through [the API](#)).

Lastly, we have the **open/close sensor**, which should be connected to a push button (a switch can do the trick too, but then it will have to be toggled and untoggled to mimic a push button) to open or close the roof, and the **master close**, which forces a close. In both cases, the command will be enforced regardless of what other connected clients have selected (more on this in the [control panel section](#)).

## **2.2. Power inputs and outputs**

Let's now take a look at how to connect the rest of the devices mentioned in the sticker. Current, be it AC mains (max 240V) or DC from a battery or power supply, will enter the Starling via the power inputs and will be blocked or routed to the output side.

The internal wiring is as follows:


- “COM” will be internally routed from the input to the output side, always.
- “NO” (Normally Open) will be connected to “IN” when the relay is closed by the software.
- “NC” (Normally Closed, only available in the extra relays and the dehumidifier), will be connected to “IN” when the relay is open in the software

When the Starling is unpowered, all the relays will be in the relaxed (normal) state, so:

—All “NC” contacts, present in the first four relays will be connected to their matching “in” (so they'll be closed)

—All “NO” contacts, will be, of course, just open.

If there's any doubt, the following image may help.



So now we have all the information we need to wire our devices to the Starling. Note that **the names of the three extra devices can be customised** in the software (more on this [later](#)), and you may find it helpful to stick the names of whatever you're plugging in onto the Starling itself.

The key things to remember here is that:

—neutral (AC) or ground (DC) should be wired to “COM” (common)

—phase or live (AC) or positive (DC) should be wired to “IN”

Also, for reference, the LED for each relay will be on when the relay is closed.

**Note:** the box of the unit must be connected to ground (earth). To achieve this simply wire the banana-style socket to earth.

The rule is simple—all A.C. current appliances should be earthed. Even if all current routed by the Starling is D.C., the box should be earthed. The circular socket on the box is there for that purpose (it's connected to the box itself).


So now you should be able to wire the devices according to the information on the sticker.

### 3. The Starling's web server

The Starling comes with an internal web server that can be accessed via its IP address or its name (<http://{ip-address}>, <http://starling>, <http://starling.local>—where “starling” will be replaced by its name if a different one has been assigned), and offers full control of the device, as well as information about the different users connected to it and a number of other features we will delve into below.


This web server (other than the `/public` page, the control panel for users) is **password-protected** to ensure only the sentinel can access it directly (users will interact with the device via the ASCOM driver or the public panel). It is also accessible from a mobile device via the same address.

Tip: if you're planning on using the web server from your phone, consider pinning it to the homepage, that'll make it easily accessible and give it an app-like feel!



### 3.1. The homepage

The homepage includes buttons for each of the other pages, as well as the *Diagnostics information* box, which displays information about the device and its current state.




### 3.2. The control panel

The control panel features easily accessible buttons to open and close the roof, as well as to abort roof operation. However, note that as the sentinel, when pressing the open or close roof buttons, **these act like any other user's request** (i.e. if conditions are safe and there are still users wanting the roof open, even if you request to close the roof, it will remain open until one of those conditions changes). If you wish to override other users you will need to use the *master close* or *Open/Close* inputs.

The peripherals list shows the 6 relays that can be controlled at will (the other two are the roof control relays and should not be changed manually). The *Extra 1*, *Extra 2*, and *Extra 3* relays don't have a fixed function and can be used for whatever you wish. They have **editable names** (just hover over them and you'll see a pencil to edit) that will be stored in the device and will show up across all pages (including the public control panel), regardless of where you're accessing the Starling from.


Toggling the relays requires double-clicking, to ensure they're only ever changed intentionally.

Under the relay toggles, there is a toggle (which also requires a double-click) to enable the security override. This override is temporary, where temporary here means it won't persist through a reboot, but it's not time-dependent. Enabling the persistent manual override (from the [configuration page](#)) will turn this off automatically, as it would be redundant otherwise.



### 3.3. The relays and sensors page


The relays and sensors page is fairly straightforward, here you can access the relays (again, except for the roof control ones, which shouldn't be changed manually), and the readings of all the sensors.




The safety information box is present in most pages, and here you can see that aside from the first banner (“System running normally”), which depends on the state of the device, the rest are associated with sensor readings. The cloud is the unsafe sensor, the lightning bolt is the power fail, and the emergency icon is, you guessed it, the emergency sensor. The other banner corresponds, of course, to the security override sensor (and virtual toggles).

### [3.4. The software and firmware updates page](#)

You shouldn’t need to access the updates page often. From it, you can reboot the system (you can do this from the configuration page as well), and verify if the software and firmware are up-to-date. If they aren’t, this page also allows you to update them.



When pressed, the *Check for Software Updates* and *Check for Firmware Updates* buttons will take a couple of moments to load and then will either show that the system is current, or the option to update it.



### 3.5. The configuration page

The configuration page is also unlikely to be one you frequent. The settings here are mostly self-explanatory. A few things worth noting, though:

- If you change your Starling’s name, this will take some time to propagate. For more noteworthy limitations, check out the [disclaimers](#) section.
- Should you lose your Starling after changing the DHCP settings or the IP address, you have more information [on this page](#) about how to retrieve it.
- The *Sentinel connection expiration timeout* refers to how long it takes for the sentinel to be considered inactive (and hence removed from the list of active users). 30s is the equivalent of the sentinel being considered like any other user.

—Enabling the *Flaps* will turn relays 2 and 3 into flap relays, and they'll become inaccessible (the flaps open will be toggled automatically when the roof starts to open, and analogously for the flaps close).

—After making changes, please **wait until the settings have stopped loading** before leaving the page, to ensure they are applied properly. Loading takes a bit as the page double-checks the changes have persisted, but again, these settings won't be modified often, so please be patient when you do make changes to prevent any issues.


The screenshot displays the 'Configuration' page of the Sentinel web interface. It is divided into three main sections:

- Network Configuration:** Contains fields for Device Name (e.g., starling), Internet Test Address (www.google.com), Internet Test Port (80), Web Server Port (80), Use DHCP (checked), IPv4 Address (192.168.3.14), Network Mask (255.255.252.0), and Gateway (192.168.3.3). A 'Set Name' button is next to the Device Name field.
- Other Settings:** Contains fields for Open/close timeout (600 seconds), Flaps (checked), Limit switches (NO selected), Sentinel connection expiration timeout (1 day selected), Close roof if no active clients (checked), and Manual security override (unchecked). 'Apply Now' and 'Cancel' buttons are at the bottom.
- Access Settings:** Contains fields for Access Username (Username for web login), Access Password (New password), and Confirm Password (Confirm new password). 'Update Credentials' and 'Cancel' buttons are at the bottom.

### 3.6. The public panel

The public panel isn't part of the sentinel's commonly accessed panels, but it's worth noting as it is the part of the web server that clients can use to interact with the roof. Clients can use third-party software to interact with the roof via the

ASCOM driver (INDILib support coming soon!), or the public panel (available across devices, just like the rest of the web server). For more information, please refer to the [Starling roof user's minimanual](#).



## 4. Starling API

Aside from through the Starling's web interface, you may wish to communicate with it in other ways. This can be done through the Starling's API, which comprises a series of commands that can be sent via http to it (and are in fact the ones used by the [public Starling panel](#)). These should have the following structure:

```
http://starling/api/v1/command_group/command/param1/param2
```

Where:

- starling* may be replaced by the appropriate name or IP address,
- api/v1* for the first version of the API,
- the commands are SLP commands, if you're familiar with our devices you may already know the Seletek Line Protocol, but this is explained in the next section.

### 4.1. SLP commands

All Lunático products can be accessed and programmed in a number of ways. Scripting, directly or ASCOM, is always available for Windows, and there are also several options for lower level integration.

When it comes to Seletek-related products (this means almost all of them, including the Starling), the protocol is the same, we call it "SLP" (standing for Seletek Line Protocol). In this section we will cover a few commands relevant to the Starling and all in the context of http, if you're after more specific information please refer to [this guide](#), or [email us](#).

The following table includes commands per group, with parameters (here separated by forward slashes) and notes. Please note that extra parameters will be ignored and missing parameters will default to 0.

As an example, the first command could be sent to the Starling as:

<http://starling/api/v1/reliao/relayreadall>

And may return something like:

!reliao relayreadall:20#

Where 20 in binary is 0001 0100, i.e. all relays are open except for the third and the fifth.

Group	Command	Parameters	Returns
reliao (Relay and sensor box)	relayreadall	—	Byte with 8 relay status values
	sensorreadalldig	—	Byte with 8 sensor as dig status values
seletek (System)	getdhcp	—	
	setdhcp	0 for on, 1 for off	
	gettip	—	The IP address
	settip	The new IP address (in text format)	
	applynetc	—	Applies the main network parameters (including the ones above) and makes them persistent
shutter	open	—	
	close	—	
	abort	—	
	physstatus	—	Actual status of the roof (as opposed to the curated status for driver compatibility)
	status	—	ASCOS compliant status

## 5. Disclaimers

The fact that the Starling's main access point for most of the configuration and monitoring is its internal web server makes it conveniently accessible across devices without need for apps and wirelessly. However, like with everything, this system isn't entirely bulletproof, and some limitations associated with the usage of a third-party browser (whichever one you may choose) are unavoidable.

For example, the Starling's tab has to be focused for it to continue sending requests to the device consistently, as **browsers may otherwise sleep the tab** to save energy. In many cases this won't matter, but if you wish to remain an active client and you're using the web server (whether it be the public panel or one of the sentinel-only pages), you'll need to keep this in mind.

Browsers also have a tendency to **cache the contents of pages** to save time and avoid having to load it all every time. This is mostly fine, but in situations like after an update, to ensure the contents (and backend functionality!) of the pages are consistent with the current version, you will need to force a reload of the page (hold the *Shift* key and press the reload button).

Another thing to keep in mind is that name changes take a long time to propagate, as mentioned in the [configuration page section](#). This will hardly be an issue as changing the name of the unit is something that usually is done just once at the beginning of its life, but it's noteworthy to prevent confusion when the changes take a long time to take effect.

---